

## Microphone Quick Guide



### Battery Installation

#### Tabletop Microphones

Turn the microphone over to find the tab on the back. Pull this tab towards the center to release the battery door.




Once the battery door has been removed, place the provided batteries into the compartments as shown on the print in the cavity.



Replace the door once the batteries are inserted.

#### Wearable Microphone, XLR and TA4 adapters

Turn the microphone so its back is facing you, and remove the battery compartment door from the bottom by pushing it towards the back.



Slide the provided battery into the compartment, making sure the tab is facing out to ensure correct placement.



Replace the door once the battery is seated correctly.

### Charge Microphones

Place the microphones in the charger so that the charging connectors of the microphone and the connectors in the charger are lined up. Magnets in the microphone and charger will help position the microphones correctly and hold them in place.



The LEDs on the Microphones will turn yellow, and then solid red, to show that the batteries are charging. Once the batteries in the microphone are fully charged, the LEDs will turn green.

Allow the batteries to charge fully before using the microphones for the first time.

### Pairing of Microphones

Before using the wireless microphones, they need to be paired to an Elite system. Please ensure that the microphone is in range of the Remote Antenna of the Elite system while pairing.



To start pairing, the microphone must be off. If the LEDs on the microphone are blinking, hold a finger on the touch area or mute button of the microphone until the LEDs turn solid red. Release the touch area or mute button and the microphone will turn off.

Next place the channel you want to pair the microphone into pairing mode. This can either be done from the front panel of the Elite system by going to Main Menu > Microphone Management or by using the local web UI of the Elite Base DSP.

From the Microphone Management Menu on the front panel, select the pair all wizard or a specific microphone channel to put into pairing mode. From the local web UI either use the pairing wizard offered during start-up or select the pair button of a channel in the "Monitor" or "Microphone Audio" pages.

Similarly the microphone needs to be put into pairing mode. Hold a finger on the touch area or mute button of the powered off microphone. The light will go solid green, then solid red. Release the mute button or touch area, the microphone is now in paring mode.

Once pairing is successful, the microphone will start blinking either red or green, based on the mute state of the microphone at start-up. Depending on the interface that was used for pairing, the front panel or web interface of the Base DSP will show a success message.

If the pairing failed and the microphone LEDs are blinking green-red-green, turn off the microphone and try pairing it again. If the problem persists, please visit <https://uc.yamaha.com/resources/support/>