


# TÄRKEITÄ TURVALLISUUSOHJEITA



Yllä oleva varoitus on laitteen pohjassa.

## • Symbolien selitys



Tasasivuisen kolmion sisällä oleva salaman kuva varoittaa käyttäjää laitteen suojakuoren sisällä olevasta, eristämättömästä vaarallisesta jännitteestä, joka saattaa olla kyllin suuri aiheuttaakseen sähköiskuvaaran ihmisille.



Tasasivuisen kolmion sisällä oleva huutomerkin kuva tarkoittaa, että laitteen mukana toimitetussa käyttöohjeessa on tärkeä käyttö- tai huolto-ohje.

- 1 Lue nämä ohjeet.
- 2 Säilytä nämä ohjeet.
- 3 Noudata varoituksia.
- 4 Noudata ohjeita.
- 5 Älä käytä laitetta veden lähellä.
- 6 Puhdista laite vain kuivalla liinalla.

- 7 Älä tuki ilmanvaihtoaukkoja Sijoita laite valmistajan ohjeiden mukaan.
- 8 Laitteen lähellä ei saa olla lämmönlähteitä, kuten lämmitinlaitetta, takkaa, uunia tai käytön aikana lämpenevää laitetta, esimerkiksi vahvistinta.
- 9 Älä muunna verkkojohtoa.
- 10 Sijoita verkkojohto siten, ettei sen päälle astuta eikä se taitu tai jää minkään alle. Suojaa erityisesti molemmat pistokepäät.
- 11 Käytä vain valmistajan suositamia lisätarvikkeita.
- 12 Laita vain valmistajan suositamalle tai laitteen mukana myydylle jalustalle tai telineeseen. Jos laite on telineessä, siirrä sitä varoen, jotta putoava laite ei aiheuttaisi vahinkoja.
- 13 Irrota verkkojohto ukonilman ajaksi tai jos laitetta ei aiota käyttää pitkään aikaan.
- 14 Anna huoltoliikkeen asiantuntijan tehdä laitehuolto. Asiantuntijaa tarvitaan, jos laite on jollakin tavoin vioittunut, verkkojohto on rikki, laitteen sisään on päässyt nestettä tai jokin esine, laite on ollut saateessa tai kostunut, laite ei toimi normaalisti tai laite on pudonnut.



## TÄRKEÄÄ

Kirjoita laitteen sarjanumero tähän:

MALLI

Sarjanumero

Sarjanumero on laitteen pohjassa. Säilytä käyttöohje tulevaa tarvetta varten.

## FCC INFORMATION (USA)

### 1 **IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!**

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

### 2 **IMPORTANT:** When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product **MUST** be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

### 3 **NOTE:** This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices.

This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices.

Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures: Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to coaxial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America A/V Division, 6600 Orangethorpe Avenue, Buena Park, CA 90620, USA.

The above statements apply **ONLY** to those products distributed by Yamaha Corporation of America or its subsidiaries.

## SÄÄNNÖSTEN VASTAAVUUTTA KOSKEVA ILMOITUS

Responsible party	Yamaha Corporation of America A/V Division
Address:	6600 Orangethorpe Avenue, Buena Park, CA 90620
Telephone:	714-522-9011
Type of Equipment:	Wireless Streaming Speaker
Model Name:	WX-051

\* Koskee vain laitteita, joiden jakelijana on YAMAHA CORPORATION OF AMERICA.

## FCC/IC NOTICE (U.S.A. and Canada)

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure evaluation (MPE).

This device complies with Part 15 of FCC Rules and Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of this device.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

(for Canada)

5150-5350 MHz band is restricted to indoor operation only.

High-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

## CAN ICES-3(B)/NMB-3(B)